



KYOCERA

DURA SPORT
5G
RUGGED RELIABILITY

DURASPORT 5G AS A MOBILE HOTSPOT



The mobile hotspot capability on your Kyocera DuraSport 5G smartphone allows you to turn your phone into a sharable Wi-Fi hotspot. And, when paired with 5G coverage, your office can be virtually anywhere!

TO SET UP THE HOTSPOT FEATURE ON YOUR DURASPORT 5G

1. From the Home screen, swipe up to access the Apps launcher screen and tap **[Settings] > [Network & internet] > [Mobile Hotspot & tethering] > [Mobile Hotspot]**
2. Tap the **[OFF]** icon under Mobile Hotspot to toggle the hotspot capability on
3. Optionally, select the desired **Security** (WPA3-Personal, WPA2 PSK (default), or None)
4. Share the Hotspot name and password with your group (you can also share via a self-generated QR code)
5. Confirm the Hotspot active icon (📶) appears at the top of the status bar
6. The number of connected devices is shown in the icon on the status bar or you can see how many devices are connected under , go to **[Settings] > [Network & internet] > [Mobile Hotspot & tethering] > [Mobile Hotspot] > [Advanced Mobile Hotspot settings] > [Connected devices]**


PREVENT HOTSPOT FROM TURNING OFF DUE TO INACTIVITY, OR TO USE QUICK SETTINGS TO QUICKLY TURN HOTSPOT ON/OFF:

1. If you plan on using the hotspot for an extended period and don't want it to turn off automatically after periods of inactivity: Tap **[Advanced Mobile Hotspot settings] > [Timeout settings]** and tap **[Never turn-off]**
2. Alternatively, use the quick setting to turn Hotspot ON/OFF as needed and allow it to turn off after inactivity to save battery power. To access quick settings, simply swipe down from the top of your home screen and add the hotspot icon.

PERSONALIZING YOUR HOTSPOT FEATURE (OPTIONAL)

1. To edit your Hotspot name (SSID – Service Set Identifier) tap **[Hotspot name]** enter a new name and tap **[OK]** to save
2. To change the password, tap **[Hotspot password]**, enter a new password and tap **[OK]** to save

To conserve battery, keep the display off and connected to the AC adapter that came with your device.



For more information, email Kyocera Sales at CEGSales@kyocera.com.