

READY FOR THE UNEXPECTED



Highlights

- Have no fear of water—waterproof protection from blowing rain (IPX5) and immersion in up to 3.28 feet (1 meter) of water for up to 30 minutes (IPX7)**
- Hear clearly in more places than ever before—place the phone anywhere against your ear to take calls in the noisiest environments with Kyocera Smart Sonic Receiver technology
- Powerful new technology that's a breeze to use—wireless charging, Touch and Send NFC sharing, and Eco Mode with MaxiMZR
- As simple as it is smart—an easy-to-use, optional Starter Mode UI with features like a tap-based menu, large fonts, and large, intuitive graphics encourages you to explore and understand the full functionality of this phone
- Work and play more—global-ready 4G LTE Android

Additional Features

- Qi-enabled wireless charging support repowers the battery; simply set your phone on an optional charging-pad accessory
- Touch and Send NFC sharing lets you share contacts, videos, apps, and more by simply touching two NFC-enabled phones back to back
- Powerful 2100mAh Li-ion battery plus added energy-saving features—Eco Mode with MaxiMZR extends performance automatically by powering down noncritical functions
- 8MP camera and camcorder with digital zoom, LED flash, auto-focus; includes panoramic, HDR, multi-shot, and smile-shutter modes
- 1.3MP front-facing camera for video chat and self-portraits
- Shoot video in 1080p HD
- Media player and high-quality video streaming at 30fps
- 1.5GHz dual-core processor for running multiple apps simultaneously and running videos seamlessly
- MagniFont Mode—enlarges on-screen text, creating an easy-to-read display
- Kyocera Keyboard settings offer choice of a traditional phone keypad layout or a QWERTY layout with Glide for quick text input
- Gmail™ and Exchange address book integration
- Corporate (Exchange ActiveSync) and personal (POP3 & IMAP) email
- 3-axis accelerometer, proximity sensor, ambient light sensor, and digital compass
- Wi-Fi® (802.11 a/b/g/n), 2.4GHz/5GHz
- Mobile Wi-Fi hotspot capability (up to ten 4G or five 3G connections)†
- Isis™ Mobile Wallet support
- MHL support for connecting phone to an external display: TV, projector, etc.
- DLNA support for sharing media wirelessly
- Stereo Bluetooth® (4.0 + LE/EDR) wireless technology support
- 3.5 mm stereo headphone jack
- Supports English and Spanish
- Hearing Aid Compatibility (HAC) Rating: M3/T3

Technical Specifications

Talk Time:

Up to 13 hours*

Standby Time:

Up to 9.84 days (236.21 hours)*

Battery Type:

2100mAh Lithium ion (Li-ion)

Display:

4.3" impact-resistant, capacitive touchscreen, HD (1280 x 720 pixels)

Operating System:

Android™ 4.1 (Jelly Bean)

Chipset:

MSM8960 @ dual-core 1.5GHz
(QUALCOMM Snapdragon processor)

Radios:

CDMA 1xRTT, CDMA 1xEVDO, LTE, GSM, EDGE, UMTS, HSPA+, GPRS

Memory:

16GB ROM/1.5GB RAM
MicroSD™ memory card slot (supports up to 32GB)

Size:

4.82" x 2.38" x .43"
(122.4 mm x 60.4 mm x 10.8 mm)

Weight:

4.51 oz. (128 g)

Media Formats:

Audio: AAC, AAC+, eAAC+, AMR-NB, AMR-WB, MP3, QCP(13KQCELP, EVRC), MIDI, OGG, WAV, WMA ProPlus
Video: H.263, H.264, MPEG4, WMV
Image: JPEG, GIF, PNG, BMP

*Times will vary based on user settings, feature use, and network configuration.

**Hydro ELITE meets IPX5 and IPX7 standards for water spray and immersion for up to 30 minutes at a depth up to 3.28 feet (1 meter).

To ensure that your phone maintains its waterproof capability, the following precautions must be observed:

- Make sure the battery cover is properly seated by squeezing around the edges of the cover. The charger/data port and audio/headset jack have no covers but they are waterproof.
- Do not spray or immerse your phone in liquids other than fresh or tap water, such as detergent, beverages, saltwater, or chlorinated or treated water
- Do not expose your phone to water heated in excess of 104°F (40°C).
- The touch panel and touch keys will not operate when the phone is wet.
- Your phone is inoperable under water and should be dried as quickly as possible when wet.

If your phone gets wet:

1. Do NOT open the battery door.
2. Wipe the phone surfaces with a dry clean cloth.
3. Hold the phone tight and shake it until no water drops come out of it.
4. Water in the phone's open ports may affect sound quality and should be removed with puffs of air directly into the ports. Phone audio may not operate properly until ports are dry. Apply a dry clean cloth to the areas of the microphones, speakers, power/lock key, volume key, audio/headset jack, and charger/data port to remove the moisture left on the phone.
5. Should your phone be accidentally exposed to liquids other than clean freshwater, rinse the phone gently in clean freshwater before performing steps 1-4 above.

Included Accessories

- Standard battery
- AC charger (Micro-USB data cable pluggable)
- Micro-USB data cable



†Additional fees may apply.

Visit our website at www.kyocerasmartphones.com
For Frequently Asked Questions, please visit Kyocera-Wireless.com.

Kyocera Communications Inc., 9520 Towne Centre Drive, San Diego, CA 92121
USA 1-800-349-4188, Outside USA 1-858-882-1410

©2013 Kyocera Communications, Inc. (KCI), San Diego, California, USA. All rights reserved. No reproduction in whole or in part is allowed without prior written approval. Kyocera is a registered trademark of Kyocera Corporation. CDMA2000 is a registered trademark of TTA USA. Gmail and Android are trademarks of Google, Inc. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks is under license. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. All other marks are held by their respective owners.

Features and specifications are subject to change without notice. Non-metric weights and measures are approximate. Not all products may be available in your area.